



# Parts for Snapper Winch

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Body Back	D1A SW	16	Spindle Hex Nut	D6F SW
2	Clamp Jaw Moving	D2B SW	17	Spindle Washer	R6J5
3	Clamp Bolt	D2C SW	18	Friction Tube	R7A4
4	Guide Assembly	D3A SW	19	Drag Washer Metal	R7B6
5	Guide Roller Only	D3B SW	20	Drag Washer Fibre	R7C6
6	Spool Only	D4A SW	21	Drag Adjust Nut	R7D5
7	Spool Complete	D4C SW	22	Handle Plate	D7E SW
8	Handle Only	D4D RM	23	Drag Pawl	R7J2
9	Handle Screw	D4E RM	24	Drag Pawl Spring	R5G1
10	Handle Assembly	D4F RM	25	Drag Lever Spring	R5H1
11	Handle Lock Nut	D4G RM	26	Drag Lever	R5C2
12	Handle Plug	D4H RM			
13	Ratchet Assembly	R5E6			
14	Spindle	D6A SW			
15	Spindle Screw	R6E4			